



ASSEMBLY INSTRUCTIONS FOR DRYWALL CART - DWC

1. First, you will attach the casters. The (3) swivel casters will use an additional caster plate and be attached using the 1.25" bolts provided. The swivel brake caster will be attached with no caster plate.

NOTE: Swivel brake caster hardware needs to be assembled as shown below. The bolt must be inserted from the bottom and secured on top with the nut. Failure to do so could result in caster not swiveling properly and could cause the cart to shift.



2. Next, assemble the upright by using the U-shaped top, the (2) short upright tubes, and hardware. Once the tubes have been connected to the top, lower the assembly onto the base and secure with hardware. Leave all hardware loose at this time.
3. Install the back support braces to both the top of the upright and the back of the base. Once complete, tighten all hardware.

SAFETY NOTES:

- Only use cart on flat surfaces
- Ensure the lock on the caster is set before loading and unloading
- DO NOT EXCEED the 2000-lb weight capacity
- Maximum material height is not to exceed 48"
- Maximum material length is not to exceed 22.5"
- Be sure load is secured before moving cart

WHEN YOU RECEIVE YOUR SHIPMENT, COMPARE NUMBER OF PIECES RECEIVED WITH YOUR PACKING LIST. IF FURTHER INFORMATION IS REQUIRED PLEASE CALL 800-991-2120.

GROVES INCORPORATED™

Manufacturer of Glass and Stone Storage Systems

WWW.GROVES.COM

818 Trakk Ln. Woodstock, IL 60098

Phone: 800-991-2120 // Fax: 815-385-8640

