



# ASSEMBLY INSTRUCTIONS

## Heavy Duty Transport Rack (TR6K)



WEIGHT CAPACITY: 6,000 lbs. - 3,000 lbs. per side

**TR6K (A-Frame):** 84" x 41" x 53" / WEIGHT: 285 lbs.

**TR6K-Cart:** 84" x 43" x 19.5" / WEIGHT: 786 lbs.

APPROXIMATE ASSEMBLY TIME: 15 MINUTES

**PARTS FOR ASSEMBLY:**

- A-Frame
- Base
- Cart
- Hold Down Bars
- Swivel Casters x4
- Rigid Casters x2

**TOOLS NEEDED:**

- Wrench
- Forklift

1. Attach six casters to the underside of the cart:
  - Attach four swivel casters at the corners.
  - Attach two rigid casters to the middle sections.
2. Attach and bolt the A-Frame to the Base.
3. Lift the combined base and A-frame with a forklift to place onto the cart. Be sure it is centered on the cart.



**Safety Note:**

Do not exceed the weight capacity of 6,000 lbs. (3,000 lbs. per side), and the load height of 40".



PROPER SECUREMENT  
OF HOLD DOWN BARS

WHEN YOU RECEIVE YOUR SHIPMENTS, COMPARE NUMBER OF PIECES RECEIVED WITH YOUR PACKING LIST. IF FURTHER INFORMATION IS REQUIRED PLEASE CALL 800-991-2120 FOR ASSISTANCE.

818 Trakk Ln. Woodstock, IL. 60098 // [www.grovesglassandstone.com](http://www.grovesglassandstone.com) // [sales@groves.com](mailto:sales@groves.com)

