

Groves Incorporated

Manufacturers of Ready Rack and Groves Glass & Stone Storage Systems
818 Trakk Lane, Woodstock, IL 60098 - USA Phone: +1 800-991-2120 Fax: 815-338-8640
www.groves.com e-mail: sales@groves.com

General Use and Safety Guidelines

GLASS SHOES (SH-4.75, SH-6.75, SH-8.5, SH-10.25, SH-13.5)

1. Inspect shoes and pins for wear and damage before each use.
2. It's important to use Groves' glass shoes each time an un-cased stoce pack of glass is lifted. Over time, the raw edge of glass will cut and fray the slings' protective covering and the woven polyester webbing and create an unsafe situation when lifting. Groves' shoes are available in five widths and should accommodate most thicknesses of glass stoce packs. When fitting the shoes, choose the width that minimizes the open space remaining after the pack of glass is placed inside. Also, do not allow a tight fit to the glass. Before lifting, center the glass inside the shoe, keeping the open space on either side as even as possible. Be sure the included pin is always inserted through the base of the shoe, underneath the sling (see Figure 1 below).



Figure 1

IMPORTANT NOTE: If you have questions concerning any of the above guidelines, or any product not specifically mentioned, please contact Groves Incorporated immediately for further information. 800-991-2120.



Warning: This product can expose you to chemicals including Di (2-ethylhexyl) Phthalate (DEHP), which is known to the State of California to cause cancer or birth defects or other reproductive harm. For more information go to www.p65warnings.ca.gov.